

OPERATING AND COMMISSIONING INSTRUCTIONS

OPERATING AND COMMISSIONING INSTRUCTIONS

I. RECEVING THE EQUIPEMENT	3
I.1. Checks on reception	3
I.2. Unpacking	3
I.3. Storing	3
I.4. End of life	3
I.5. Handling	3
I.6. Space required	4
I.6.b. BFIL EC LOBBY	4
I.7. Installation	4
I.8. Setting up a filter	5
II. GENERAL FONCTIONNING	5
II.2. BFIL EC LOBBY	5
III.1. BFIL EC LOBBY	6
III.1.a. External 0-10V connection	7
IV.2. BFIL EC LOBBY	7
III.2.a. BFIL EC LOBBY 125-160	7
III.2.a. BFIL EC LOBBY 200 - 250	8
III.2.a. BFIL EC LOBBY 315-400	8
III.2.b. Connection of the pressure tube	8
IV. SETTING BFIL EC LOBBY	9
IV.1.a. Presentation of the controller	9
IV.1.b. Arborescence des menu et paramétrage	10
V. MAINTENANCE	11
V.1. Exterior of the box	11
V.2. Fan	11
V.3. Electrical connection	11
V.4. Filtration	11
VI.REPAIR	11
VI.2. BFIL EC LOBBY	11
VII. MODBUS	12
VII.1. BFIL EC LOBBY	12
VIII.NOTES	12

OPERATING AND COMMISSIONING INSTRUCTIONS

SAFETY INSTRUCTIONS AND COMPLIANCE WITH REGULATION

In compliance with the current norms, the machine should be installed only by a technical person qualified for this type of work.

Use the required personal protection devices so as to avoid injuries caused by electrical and mechanical hazards (injuries by touching panels, sharp edges, etc.). Use EN170 protective eyewear and ear protection.

Do not use the unit for an other use than design use (Usage in accordance with the intended purpose).

This unit can't be used for dangerous air extraction or supply.

Move the machine as detailed in chapter *handling*.

Grounding has to be carried out in compliance with current standards. Never start the device without grounding.

Before any intervention ensure that device is powered off and wait for complete stop of every rotative component such as damper, fan, rotative exchanger...

During device's run inspection doors must be mounted and closed.

Start has to be done only with padlockable switch.

Do not shut off or short circuit the safety and control equipment.

During interventions, be careful with hot components such as hot water coil or electric resistances.

The machine should be installed in compliance with fire norms.

The waste must be disposed off in compliance with the current standards. No packaging should be discarded into the environment.

We disclaim any responsibility for any damages resulting from wrong utilisation of the equipment, reparation, modification or no compliance with these instructions.

The device must be installed in accordance with the regulations and rules of the art in force in the installation country.

I. RECEIVING THE EQUIPMENT

The units are delivered on stringers or pallets then wrapped in plastic film

I.1. Checks on reception

When the equipment is received, the state of the packaging and the equipment must be checked. In the event of damage, make an accurate note of any problems on the carrier's delivery note

I.2. Unpacking

When the equipment is unpacked, check the following:

- The total number of packages is present.
- All accessories are present. After unpacking the equipment, the waste must be disposed off in compliance with the current standards. No packaging should be discarded into the environment

I.3. Storing

The equipment must be stored in shade, in a dry place, at a temperature between -20°C and 40°C. The packaging can't be considered sufficient for an external storage.

I.4. End of life

At the end of the life of this equipment, the user contacts the distributor who will propose a collection solution or a place of deposit for the product.

I.5. Handling

The units must only be moved in their installation position.

If the device is handled using a fork-lift truck, ensure this supports the load-bearing structure.

If the device is moved using a crane, use four cables of identical lengths. These must be at least as long as the greatest distance between two fastening points.


If L + W + H > 5m P then the case must be lifted using a lifting beam

OPERATING AND COMMISSIONING INSTRUCTIONS

I.6. Space required

Generally speaking, it is desirable to provide access space for maintenance. We advise 1 time unit height on each side for maintenance.

I.6.b. MINIBLUE



Range MINIBLUE®	A mm	B mm	C mm	Ø mm	D mm	E1 mm	E mm	G mm	Weight kg
125	515	260	370	125	120	185	185	50	12
160	515	260	370	160	120	185	185	50	12
200	590	290	420	200	125	210	210	60	16
250	540	360	450	250	165	225	225	60	19
315	470	385	450	315	205	225	225	60	23
355	570	475	550	355	275	275	275	60	30
400	570	475	550	400	250	275	275	60	31

I.7. Installation

The unit must be suspended or laid on a sufficiently rigid and flat surface (use vibration mounts if necessary). For the HVAC connection, select duct sections based on dimensions of the flexible bands that should be properly stretched.

Install the unit in such a way that bad weather or ambient temperature cannot damage internal items during installation or later use (provide a protective cap if necessary).

If inlet or outlet are not ducted, provide a protective grid.

Outdoor installation of boxes:

An outdoor unit must always be attached to the floor of the support frame so that it can not move or fall (take into account the force of the wind). Also provide a mesh beveled nozzle (BBG) if necessary (optional)

Indoor installation of boxes:

The devices should preferably be placed on a frame suspended from the structure of the building, taking care to respect the permissible loads (chassis at the expense of the installer).

However, the BFIL EC LOBBY systems can be suspended directly from the ceiling by M8 threaded rods connected to the brackets at the bottom of the boxes.

Aerdraulic connection:

For the ventilation connection, select the duct sections in relation with the dimensions of the flexible bands, which must be correctly tensioned. Ducting may have to be insulated if necessary. Ducting must be realized in accordance with the general building regulations (no elbow at the exit of fan before a minimum distance of 5 times the diameter of collar saddle, and in entry, no elbow before a minimum distance of 2.5 times the diameter of collar saddle).

The direction of the air is noted on the label.

OPERATING AND COMMISSIONING INSTRUCTIONS

I.8. Setting up a filter

When the filter is not mounted at the factory, the 2 rails positioned in the bottom of the box fan must be fixed using the self-drilling screws 3.9x13 supplied. 2 markers marks you where to screw from the outside. You will need to cut the rockwool over the entire height of the filter for BFIL EC LOBBY



II. GENERAL FONCTIONNING

II.1. MINIBLUE

Equipped with a proximity switch as standard, this extraction or insufflation box fan is equipped with Direct Drive DC motor with integrated thermal cutout.

Sizes 125 to 250 are equipped with reaction turbine with single opening.

Sizes 315 to 400 are equipped with impulse turbine with double opening.

They are also equipped with a potentiometer for a suitable and optimal adjustment of the flow.



OPERATING AND COMMISSIONING INSTRUCTIONS

III.1. MINIBLUE

Range MINIBLUE®	Power supply voltage (V / Ph / Hz)	Power rating (W)	Protection current (A)	Usage Temp (°C / °C)	Motor IP / Class	Thermal cutout*
MINIBLUE® 125	230 / 1 / 50	83	0,75	-25 / 60	IP54 / B	PTI
MINIBLUE® 160	230 / 1 / 50	83	0,75	-25 / 60	IP54 / B	PTI
MINIBLUE® 200	230 / 1 / 50	85	0,7	-25 / 60	IP54 / B	PTI
MINIBLUE® 250	230 / 1 / 50	170	1,4	-25 / 60	IP54 / B	PTI
MINIBLUE® 315	230 / 1 / 50	1070	4,3	-25 / 40	IP44 / F	PTI
MINIBLUE® 355	230 / 1 / 50	1040	4,5	-25 / 40	IP44 / F	PTI
MINIBLUE® 400	230 / 1 / 50	1040	4,5	-25 / 40	IP44 / F	PTI

*PTI : Integrated thermal cutout

OPERATING AND COMMISSIONING INSTRUCTIONS




III.1.a. External 0-10V connection

Possibility to connect an external 0-10V:

BFIL EC LOBBY 125 to 250: disconnect the blue and yellow wire from the potentiometer (blue = 0V / yellow = 0-10V)
 BFIL EC LOBBY 355 to 400: disconnect the white and green wire of the potentiometer (white = 0V / green = 0-10V)


III.2. BFIL EC LOBBY

III.2.a. BFIL EC LOBBY 125-160




OPERATING AND COMMISSIONING INSTRUCTIONS

III.2.a. BFIL EC LOBBY 200-250



III.2.a. BFIL EC LOBBY 315-400



III.2.b. Connection of the pressure tube


Extraction (mounted as standard): The - is connected to the box and the + remains in the open air
 Blow: The + has to be connected to the blowing duct and the - remains in the open air

OPERATING AND COMMISSIONING INSTRUCTIONS

IV. SETTINGS BFIL EC LOBBY

IV. 1.a. Presentation of the controller


Setting is done entirely via the regulator preinstalled on the box



- ← Welcome screen return
- + - Change value
- OK Validate value
Access to pressure setting
Access to the service menu by long press

OPERATING AND COMMISSIONING INSTRUCTIONS

IV.1.b. Menus arborescence and parameters



Screen Explanations

Screen 1 : Main screen

--Pa : Actual pressure

State : « AUTO » = normal run / « BOOST » = fire exhaust on / « OFF » = Stop by external contact

Alarm: Displayed if the pressure is <80Pa. In this case the screen lights up in red and green

Screen 2 : Pressure setpoint

--Pa : Actual setpoint (150Pa default value)

Screen 3 : PID settings

PBand : Proportionnal Band (500Pa default value)

ITime : Integer (40s default value)

Screen 4 : Output 0-10V

MINI : 1V (default value)

MAXI : 10V (default value) → Do not change

Screen 5 : MODBUS

See chapter IX.1

Screen 6 : Set to zero

Calibration of the pressure transmitter.

CAUTION: Must be done with the pressure tap not connected.

To edit a value : press the ok key, change with the +/- keys and confirm with ok

OPERATING AND COMMISSIONING INSTRUCTIONS

V. MAINTENANCE

Before beginning any maintenance or repair work, it is essential to electrically isolate the box fan by opening the Proximity Lockable Switch (IPC) (OFF Position). The maintenance and decommissioning of the installations must be carried out under the conditions ensuring compliance with applicable environmental regulations. The maintenance must be ensured at least once a year or according to the applicable regulatory requirements (fire safety ...) Depending on the installation conditions, the control frequency can be further reduced.

V.1. Exterior of the box fan

Check ducts, flexible cuffs and anti-vibration pads, replace if necessary. Check that all the elements connected to the box are in place so that no vibration can be transmitted to the external element

V.2. Fan

Dust the turbine and the volute if necessary.

V.3. Electrical connection

Check connections and insulators regularly.

V.4. Filtration

The filters are to be replaced every year or more if necessary

VI. REPAIR

For any other defect or anomaly found, and in case of inefficiency of repair, contact the After Sales Service.
Defective parts must be replaced exclusively with original components (compliance with applicable product regulations)


VI.1. MINIBLUE LOBBY

Nature of the defect	Probable cause	Solutions
The box fan does not start + nothing on display	Box not powered Motor out of order	Check the presence of voltage Check that the switch is ON
The box fan does not start	Startup delay	Wait 1 minute before the box starts
The box fan does not start + OFF displayed on screen	External stop (ON)	Open the external stop
The box is at maximum ("BOOST" displayed on the screen)	TK wire (thermo safety contact) cut Extract Air above 70 °C	Restart the box Change or rewire the TK (thermo safety contact)
0 Pa displayed on the screen + « ALARME » displayed on the screen The screen flashes red/green	TP tube (pressure transmitter) disconnected TP connection problem (pressure transmitter)	Check the TP air connection (pressure transmitter, tube must be connected -) (black pressure tap) Check the electrical connection of the TP (pressure transmitter)

OPERATING AND COMMISSIONING INSTRUCTIONS

VII. MODBUS

VII.1. BFIL EC LOBBY



To access these parameters, press the OK button for 5s and follow the tree explained in chapter V.1.

Possible choice :

- Adress (1-999) → Standard 1
 - Speed (150-300-600-1200-2400-4800-9600-19200) → Standard 9600
 - 2 stop Bits (OUI-NON) → Standard OUI
 - Parity (NON-IMPAIRE-PAIRE) → Standard NON

INPUT REGISTER

adresse	Nom	description
1	Pa actual	Actual value in Pa
2	Alarm	0= No default / 1= défaut

HOLDING REGISTER

adresse	Nom	description
3	Pressure setpoint	Chose the pressure setpoint in Pa

VIII. NOTES