

# Inverter Air Source Water Heat Pump

---

Floor heating and Air-con Unit

**Installation and Instruction Manual**

**For outdoor installation only**





# CONTENT

1	Preface	1
2	Safety Precaution	2
	(1) Mark notes	2
	(2) Icon Notes	2
	(3) Warning	3
	(4) Attention	4
3	Specification	5
	(1) Appearance and structure of the heat pump	5
	(2) The data of unit	5
	(3) Unit dimension	6
4	Installation	8
	(1) Application of heat pump	8
	(2) Choose a right heat pump unit	9
	(3) Installation method	9
	(4) Installation place	9
	(5) Refrigerant charging	10
	(6) Water loop connection	11
	(7) Power supply connection	11
	(8) Location of the unit	11
	(9) Transit	12
	(10) Trial Running	12
5	Operation and Use	13
	(1) Main interface display and function	13
	(2) Setting interface display and function	22
	(3) Status interface display	36
	(4) Parameter list and breakdown table	37
	(5) Interface diagram	40
6	Appendix	44
	(1) Appendix 1	44
	(2) Appendix 2	45
	(3) Appendix 3	46

# Preface

---

- In order to provide the customers with high quality, strong reliability and good versatility product, this heat pump is produced by strict design and manufacture standards. This manual includes all the necessary information about installation, debugging, discharging and maintenance. Please read this manual carefully before you open or maintain the unit.

The manufacture of this product will not be held responsible if someone is injured or the unit is damaged, as a result of improper installation, debugging, unnecessary maintenance which is not in line with this manual.

The unit must be installed by qualified personnel.

- It is vital that the below instructions are adhered to at all times to keep the warranty.
  - The unit can only be opened or repaired by qualified installer or an authorised dealer.
  - It is recommended to check the unit running status every 3 to 6 months, when the unit is turn off for a long time, it is necessary to check the operating environment such as the power and circulating water line before the unit is turn on.
  - Use genuine standard spare parts only.

Failure to comply with these recommendations will invalidate the warranty.

- Inverter air source water heat pump is a kind of high efficiency, energy saving and environment friendly equipment, which is mainly used for house warming. It can work with any kind of indoor unit such fan coil, radiator, or floor heating pipe, by provide warm or hot water. One unit of monobloc heat pump can also work with several indoor units. The air source water heat pump unit is designed to have heat recovery by using super heater which can provide hot water for sanitary purpose.

This series of heat pump unit owns following features:



- 1 Advanced controlling  
The display is available for the user to set, review and change the running parameters of the heat pump. The units can be controlled by centralized controller through Modbus RS485.
- 2 Nice appearance  
The heat pump is designed with beautiful looking. The monobloc one has the water pump included which is very easy for installation.
- 3 Flexible installation  
The unit has smart structure with compact body, just simple outdoor installation is needed.
- 4 Quiet running  
High quality and efficient compressor, fan and water pump is used to ensure the low noise level with insulation.
- 5 Good heat exchange rate  
The heat pump unit use special designed heat exchanger to enhance whole efficiency.
- 6 Large working range  
This series of heat pump is designed to work under different working conditions as low as -25 degrees for heating.

# Safety Precaution




---

To prevent the users and others from the harm of this unit, and avoid damage on the unit or other property, and use the heat pump properly, please read this manual carefully and understand the following information correctly.

## Mark Notes



Mark	Meaning
 WARNING	Incorrect operation may result in severe injury or death.
 ATTENTION	Incorrect operation can cause harm to individuals or property damage.



## Icon notes




Icon	Meaning
	Actions that are prohibited are indicated by this icon.
	Actions that must be taken are listed here.
	<b>ATTENTION</b> (include <b>WARNING</b> ) Please heed the indicated warnings.

# Safety Precaution

## Warning

Installation	Meaning
 Professional installer is required.	The heat pump must be installed by qualified personnel to prevent improper installation, which could lead to water leakage, electrical shock, or fire.
 Earthing is required	Ensure that the unit and power connections are properly grounded to prevent the risk of electrical shock.

Operation	Meaning
 PROHIBITION	DO NOT insert fingers or other objects into the unit's fans or evaporator, as this could result in injury.
 Power Shut-Off	In case of malfunction or a strange smell, immediately shut off the power supply to stop the unit. Continuing to operate it may cause an electrical short or fire.

Move and repair	Meaning
 Entrust	If the heat pump needs to be moved or reinstalled, please entrust the task to a dealer or qualified person. Improper installation can lead to water leakage, electrical shock, injury, or fire.
 Entrust	Users are not allowed to repair the unit themselves, as it may result in electrical shock or fire.
 Prohibit	If the heat pump requires repairs, please entrust the task to a dealer or qualified person. Improper handling or repairs can lead to water leakage, electrical shock, injury, or fire.






Do not use means to accelerate the defrosting process or to clean, Other than those recommended by the manufacturer.





The appliance shall be stored in a room and installed in the environment without continuously operating or potential ignition sources (for example: open flames, an operating gas appliance or an operating electric heater or Electric Spark or hot object)

# Safety Precaution

---


## ATTENTION

Installation	Meaning
 Prohibition of Flammable Gas Proximity	The unit can not be installed near any sources of flammable gas. In the event of a gas leakage, a fire may occur.
 Stable Foundation Required	Ensure that the foundation of the heat pump is strong enough to prevent any tilting or falling of the unit.
 Mandatory Installation of Circuit Breaker	A circuit breaker must be installed for the unit. The absence of a circuit breaker can lead to electrical shock or fire.

Operation	Meaning
 Regular Inspection of Installation Foundation	The installation foundation should be inspected periodically (at least once a month) to prevent any deterioration or damage that might cause injury or damage to the unit.
 Power Disconnection During Maintenance	Please switch off the power when cleaning or performing maintenance on the unit.
 Prohibition	The use of copper or iron as a fuse is prohibited. The correct fuse must be installed by a qualified electrician for the heat pump.
 Prohibition	Spraying flammable gas onto the heat pump is prohibited as it may cause a fire.

# Specification

## 1. Appearance and structure of the heat pump



## 2. The data of unit

\*\*\* REFRIGERANT : R290

Model		CWP-M 04 A1	CWP-M 06 A1	CWP-M 08 A1	CWP-M 10 A1	CWP-M 17 A1	CWP-M 10 M1	CWP-M 17 M1	
Heating Capacity Range(A)	kW	1.80~6.70	1.80~9.75	2.40~12.30	4.56~14.45	5.30~22.30	4.56~14.45	6.10~22.30	
Heating Power Input Range(A)	kW	0.49~1.49	0.49~2.08	0.68~3.10	1.19~3.78	1.75~5.50	1.19~3.78	1.28~5.50	
Heating Capacity Range(B)	kW	2.25~6.00	2.25~8.54	3.00~11.20	3.61~12.91	6.09~21.70	3.61~12.91	6.08~21.70	
Heating Power Input Range(B)	kW	0.93~1.98	0.93~3.09	1.25~4.06	1.44~5.21	2.43~7.89	1.44~5.21	2.42~7.89	
Cooling Capacity Range(C)	kW	2.10~6.00	2.10~9.40	4.80~11.00	4.16~13.50	3.20~22.00	4.16~13.50	5.84~22.00	
Cooling Power Input Range(C)	kW	0.50~1.45	0.50~2.80	0.88~4.00	1.50~4.87	1.30~8.10	1.50~4.87	2.36~8.10	
Cooling Capacity Range(D)	kW	1.60~4.80	1.60~6.89	2.2~9.10	3.12~10.47	3.90~17.10	3.12~10.47	4.52~17.10	
Cooling Power Input Range(D)	kW	0.60~1.60	0.60~2.64	0.92~4.20	1.35~4.46	1.80~7.58	1.35~4.46	1.73~7.58	
Max. Power Input	kW	2.76	3.90	5.10	6.30	8.52	6.30	9.10	
Max. Current Input	A	12.0	17.0	22.0	30.0	36.1	12.2	16.1	
Power Supply		220-240V~/50Hz					380~415V/3N~/50Hz		
Compressor Quantity		1	1	1	1	1	1	1	
Compressor Model		Rotary	Rotary	Rotary	Rotary	Rotary	Rotary	Rotary	
Fan Quantity		1	1	1	1	2	1	2	
Fan Power Input	W	55~90	55~105	55~130	60~170	30~80	60~170	30~80	
Fan Rotate Speed	RPM	600	700	770	700	800	700	800	
Water Pump Input	W	60	60	60	60	180	60	180	
Sound Pressure (1m)	dB(A)	42	45	46	46	48	46	48	
Water Connection	inch	1	1	1	1	1	1	1	
Water Flow Volume	m <sup>3</sup> /h	0.68	1.03	1.38	1.7	2.9	1.7	2.9	
Internal Water Pressure Drop	kPa	5	15	15	20	40	20	40	
Water Head	m	5.5	7.5	6.8	5.6	10.5	5.6	10.5	
Unit Dimension(L/W/H)	mm	See drawings of the heat pump							
Shipping Dimension(L/W/H)	mm	see data on the package							
Net Weight	kg	see data on the package							
Shipping Weight	kg	see data on the package							

Heating working condition(A):(DB/WB)7°C/6°C. Outlet water temp. 35 °C.

Heating working condition(B): (DB/WB) 7°C/6°C. Outlet water temp. 55 °C.

Cooling working condition(C):(DB/WB) 35°C/24°C, Outlet water temp. 18 °C.

Cooling working condition(C):(DB/WB) 35°C/24°C, Outlet water temp. 7 °C.

BS EN 14511-1-2013 Air conditioner, whole liquid cooling machine, electric compressor.


Part2: Test condition ; Part3:Test method ; Part4:related requirements.




# Specification

## 3. Unit dimension

Models: CWP-M 04 A1 / CWP-M 06 A1 / CWP-M 08 A1




Models: CWP-M 10 A1 / CWP-M 10 M1



# Specification

---

Models: CWP-M 17 A1/ CWP-M 17 M1



# Installation

## Unit features

### 1. Plate heat exchanger

Utilize the plate heat exchanger, characterized by its compact size and high efficiency.

### 2. Environmentally Friendly Refrigerant

Employ the new generation of environmentally friendly refrigerant R290, which poses no harm to the ozone layer.

### 3. Heating in Frigid Environment.

The optimally designed unit can maintain normal heating functionality even when the ambient temperature drops to  $-25^{\circ}\text{C}$ .

### 4. Refrigerant Charging


If the machine is not equipped with refrigerant and is charged with nitrogen, then the recharging of the refrigerant needs to be carried out according to the instructions on page 13.

### 5. Installation Environment

The refrigerant R290 is flammable and explosive. It is prohibited to install the unit in environments with operating or potential ignition sources, including open flames, operating gas appliances, electric heaters, electric sparks, or hot objects.

## 1 Application of heat pump

### 1.1 House Heating/Cooling + Domestic Hot Water




1	Heat pump	10	Relief valve	19	PT valve
2	Flexible pipe	11	Air vent valve	20	Electrical heater
3	Thermometer	12	Water pump for floor heating	21	Hot water sensor
4	Manometer	13	Check valve	22	Mixing valve
5	Shut-off valve	14	Floor heating valve		
6	Y type water filter	15	Hot water tank		
7	Plate heat exchanger	16	Floor heating pipe/fan coil unit		
8	Buffer tank	17	Hot water valve		
9	Expansion tank	18	Hot water pump		

Remark: Item 17, 18, 20, 21 can be connected with heat pump.

# Installation

## 1.2 House Heating/Cooling (includes Buffer tank)



1	Heat pump	7	Plate heat exchanger	13	Check valve
2	Flexible pipe	8	Buffer tank	14	Floor heating valve
3	Thermometer	9	Expansion tank	15	Floor heating pipe/fan coil unit
4	Manometer	10	Relief valve		
5	Shut-off valve	11	Air vent valve		
6	Y type water filter	12	Water pump for floor heating		

## 2 Choose a right heat pump unit

- 2.1 Based on the local climate condition, construction features and insulation level, calculate the required cooling(heating) capacity per square meter.
- 2.2 Conclude the total capacity which will be needed by the construction.
- 2.3 According to the total capacity needed, choose the right model by consulting the heat. Usually, the heat pump capacity is 1.05 times or more than the required heat production . and the heat pump operation energy-saving effect is better , pump features as below:  
Heat pump features

- Cooling mode: The heat pump operates at an ambient temperature of 10~43°C , recommended that the user set the target outlet water temperature of 7~20°C .  
Heating Mode: The heat pump operates at an ambient temperature of -25~43°C , recommended that the user set the target outlet water temperature of 30~60°C , the higher the water temperature, the worse the energy saving effect ,and maximum target outlet water temperature is 75 °C ,
- Unit application  
Inverter air source water heat pump is used for house, office, hotel, and so forth, which need heating or cooling separately, with each area need to be controlled.

## 3 Installation method


The heat pump can be installed onto the concrete basement by expansion screws, or onto a steel frame with rubber feet which can be placed on the ground or housetop. Make sure that the unit is placed horizontally.

## 4 Installation place

- The unit can be installed on any place outdoor which can carry heavy machine such as terrace, housetop, ground and so on.
- The location must have good ventilation.
- The area should be free from heat radiation and open flames.
- A cover is needed in winter to protect the heat pump from snow.
- There must be not obstacles near the air inlet and outlet of the heat pump.
- Choose a location that is free from strong winds.
- A water channel is necessary around the heat pump to drain the condensation water.
- There must be sufficient space around the unit for maintenance
- The location should be far from operating or potential ignition sources, such as open flames, operating gas appliances, electric heaters, electric sparks, or hot objects.

## 5 Refrigerant charge

If the machine is not equipped with refrigerant and is charged with nitrogen, then the recharging of the refrigerant needs to be carried out according to the instructions on page



Stop valve signs:  
Low pressure

### 5.1 Preparations

5.1.1 Please ensure a well-ventilated environment while charging the refrigerant.

5.1.2 Avoid open flames or potential sources of fire.

5.1.3 Disconnect the power supply to the heat pump.

5.1.4 Carefully check the heat pump's nameplate and charge according to the specified amount labeled.

### 5.2 Nitrogen Gas Pressure Check

Check the pressure of the nitrogen gas inside the system. The heat pump is pre-charged with about 30 Bar of nitrogen gas. Before charging the refrigerant, ensure there is still high-pressure nitrogen present; otherwise, identify and check for leakage points. (Use a spanner to remove seal nuts 1 and 3, and a 5mm inner hexagon spanner to open valve 2. If high-pressure gas is expelled, the heat pump is not leaking.)

### 5.3 Nitrogen Gas Release

Use a 5mm inner hexagon spanner to open valve 2 and release all the nitrogen gas inside the system.

### 5.4 Vacuuming the System

Connect a vacuum pump to valve 2 and run it until the absolute pressure falls below 30Pa or it has been operating for more than one hour.

### 5.5 Refrigerant Charging

Ensure the refrigerant is in a liquid state when charging and adhere strictly to the labeled amount.

### 5.6 Sealing the System

After charging is complete, close valve 2 and tighten seal nuts 1 and 3.

# Installation

## 6 Water loop connection


Please pay attention to the matters below when connecting the water pipe :

- Try to minimize the resistance to water flow within the piping.
- The piping must be clean and free from dirt and obstructions. A water leakage test must be conducted to ensure there are no leaks before proceeding with the insulation.
- Note that the pipe must undergo pressure testing separately. DO NOT test it concurrently with the heat pump.
- An expansion tank must be installed at the highest point of the water loop, and the water level in the tank should be at least 0.5 meters higher than the highest point of the water loop.
- The flow switch is installed inside the heat pump; ensure the wiring and functionality of the switch are normal and controlled by the controller.
- Try to prevent air from remaining inside the water pipe; there must be an air vent at the highest point of the water loop.
- A thermometer and pressure meter must be installed at the water inlet and outlet to facilitate easy inspection during operation.

## 7 Power supply connection

- Open the front panel, and open the power supply access.
- The power supply must go through the wire access and be connected to the power supply terminals in the controlling box. Then connect the 3-signal wire plugs of the wire controller and main controller.
- If an external water pump is required, please also insert its power supply cable through the wire access point and connect it to the water pump terminals.
- If an additional auxiliary heater needs to be controlled by the heat pump controller, the relay (or power supply) of the auxiliary heater must be connected to the relevant output on the controller.

## 8 Location of the unit



The picture shows the location of horizontal air outlet unit.




### Attention

Requirements  
A>500mm ; B>1500mm ;  
C>1000mm ; D>500mm  
E>150mm


The minimum ventilation distance in diagram 1.

# Installation


Front view:



Top view:




Apartment:



# Installation

## 9 Transit

When the unit need to be hung up during installation, a 8 meters cable is needed, and there must be soft material between the cable and the unit to prevent damage to the heat pump cabinet. (See picture 1)



Picture 1



**WARNING**


**DO NOT touch the heat exchanger of the heat pump with fingers or other objects!**

## 10 Trial Running

Inspection before trial running

- Check the indoor unit and verify that the pipe connection is correct and the relevant valves are open.
- Inspect the water loop to ensure that the expansion tank contains sufficient water, the water supply is adequate, and the loop is filled with water without any air present. Additionally, ensure good insulation is applied to the water pipe.
- Examine the electrical wiring. Confirm that the power voltage is normal, the screws are tightened, the wiring aligns with the diagram, and the grounding is connected properly.
- Review the heat pump unit, including all screws and components, to ascertain they are in good condition. Upon powering on, observe the indicators on the controller for any failure signs. Connect the gas gauge to the check valve to monitor the system's high (or low) pressure during the trial run.

Trial running

- Activate the heat pump by pressing the " " key on the controller. Check the water pump's operation; if functioning normally, the water pressure meter will indicate 0.2 MPa.
- After the water pump has run for 1 minute, the compressor will initiate. Listen for any unusual sounds emanating from the compressor. In case of abnormal noises, cease operation and inspect the compressor. If the compressor is running smoothly, proceed to check the refrigerant pressure meter.
- Subsequently, confirm that the power input and running current conform to the specifications detailed in the manual. If discrepancies are noted, halt the operation and investigate the issue.
- Adjust the valves in the water loop to guarantee the hot (or cold) water supply to each unit meets the heating (or cooling) requirements.
- Assess the stability of the outlet water temperature.
- The controller's parameters are preset by the manufacturer; unauthorized alterations by the user are prohibited.





①	Screen lock button: You can perform various operations on the display when the lock is open, but you cannot operate the display when the lock is closed. After locking the screen, press the screen lock button and enter the password to unlock the screen.
④	On/off button: when the button is displayed in blue, it means power on state, and it will turn to white as tapped and switch to power off state.
⑤	Target temperature setting button. When the button is tapped, the unit will enter the target temperature setting interface, allowing you to set the target temperature of the current mode.
⑰	Mode selection button. When the button is tapped, the unit will enter the mode selection interface, allowing you to set the mode. There are five modes : heating, cooling, hot water, hot water + cooling, hot water + heating.

# Operation and Use

---

Icon	Function
②	Main interface icon: It indicates that the current page is the main interface.
③	DHW temperature: The unit is in DHW mode when this icon is shown, otherwise this icon is not shown.
⑥	Inlet temperature: Display the control temperature: Outlet, Room, Buffer Tank, Inlet
⑦	Target temperature: Display the current mode target temperature.
⑧	Fault icon: This icon will be displayed when the unit fails ,then the display will enter Failure record interface after tapping this icon
⑨	Defrosting icon: This icon will be displayed when the unit enters the defrosting function.
⑩	Mute timer icon: This icon will be displayed after the mute timer function is enabled.
⑪	Power on/off timer icon: This icon will be displayed after the power on/off timer function is enabled.
⑫	Mode&temp.&power timer icon: This icon will be displayed when enters this timer
⑬	SG Ready Icon: This icon will be displayed when enters SG Ready, SG Ready includes five modes: Solar Sleep Mode, Solar Low Mode, Solar Medium Mode, Solar High Mode, Normal Mode
⑭	Ambient temperature: Display the current ambient temperature.
⑮	System time: Display the current real-time time. The time can be changed as required.
⑯	Running mode icon: representing the unit is currently running in DHW+heating mode. There are five modes, namely: heating, cooling, hot water, DHW+ cooling, DHW + heating


# Operation and Use

---

## 1.1 On and off


As the main interface shows

- (1) In shutting down interface (on/off key is in white status),  
press on/off key can start up the machine.



- (2) In starting up interface (on/off key is in blue status),  
press on/off key can shut down the machine.

## 1.2 Mode switch



# Operation and Use

There are five modes can be selected after sliding the mode icon.

- (1) selecting DHW mode icon, then the display will change to this mode interface;
- (2) selecting heating mode icon, then the display will change to this mode interface;
- (3) selecting cooling mode icon, then the display will change to this mode interface;
- (4) selecting DHW+heating mode icon, then the display will change to DHW+heating mode interface;
- (5) selecting DHW+cooling mode icon, then the display will change to DHW+cooling mode interface;


Note: a) If the machine model you purchased has no cooling function, the key of cooling mode will not be displayed.

b) If the machine model you purchased has no DHW function, the key of hot water mode function will not be displayed.

c) If the machine model you purchased has only DHW function, the mode interface only displays DHW icon.

## 1.3 Setting of target temperature

### 1.3.1 Disable zone control



Take DHW + heating mode for example:


- (1) Tapping ①, the wire controller back to the main interface;
- (2) Sliding ②, the target temperature can be adjusted in the clockwise or counterclockwise direction. Minimum adjustment range is 0.5°C.
- (3) Tapping ③, the target temperature can be saved.



Note: When room temperature control, click the room temperature display in the main interface to enter the room target temperature setting page, and slide the adjustment to set the room target temperature.

# Operation and Use

## 1.3.2 Enable zone control

### 1.3.2.1 Heating Mode Multi-Zone Control

When heating or DHW+heating mode, click “” to enter the multi-zone function interface:




1	Display target outlet temperature in zone 1/target outlet water temperature after compensation
2	Display room target temperature in zone 1, when Z01=4/5/6/7/8/9,it displays “/”
3	Display target outlet temperature in zone 1/target outlet water temperature after compensation
4	Display room target temperature in zone 2, when Z01=4/5/6/7/8/9,it displays “/”
5	Display outlet water temperature
6	Display inlet water temperature
7	When H25=buffer tank control, display buffer tank temperature When H25≠buffer tank control, display --- , and Buffer will become “Not used”
8	Display Tank temperature
9	When zone 1 pump turns on, display “ON”, otherwise display “OFF”
10	Display zone 1 room temperature. When Z01=4/5/6/7/8/9, it means the unit is connected to the passive switch thermostat or room thermostat, and the unit will just receives the signal, when the thermostat asks the unit to turn on, then here will show Zone1: Start, otherwise, it will show Zone1:Stop.
11	Display the percentage of zone 2 mixing valve steps.
12	Display 100 - the percentage of zone 2 mixing valve steps
13	Display zone 2 mixing water temperature
14	Display zone 2 room temperature. When Z01=4/5/6/7/8/9, it means the unit is connected to the passive switch thermostat or room thermostat, and the unit will just receives the signal, when the thermostat asks the unit to turn on, then here will show Zone2: Start, otherwise, it will show Zone2:Stop.
15	After clicking, enter password, will enter the multi-zone function parameter list.
16	Click to return the main screen.

# Operation and Use


## 1) Zone 1 target temperature setting interface

Click “ 45.0 °C” to enter the target temperature in zone 1:



Number	Key name	Key function
①	Zone 1 Set Target WT	Click to set zone 1 target outlet water temperature
②	Zone 1 Target RT	Click to set zone 1 room target temperature, when Z01=4/5/6/7/8/9, it displays “/”
③	Zone 1 AT-WT Compensation	Click to enter the zone 1 weather compensation curve, When the zone 1 weather compensation is disable, it will display Not Used. Enable to display the compensated temperature. Enable condition: Z01=1/3/4/6/7/9 and Z16=1

### Zone 1 weather compensation curve



# Operation and Use


Number	Key name	Key function
①	Enable key	Enable weather compensation button.
②	Slope	Set the slope by sliding up and down or clicking on the value
③	Offset	Set the offset by sliding up and down or clicking on the value

Celsius calculation formula: Compensated temp. = -Slope\*Current AT + Offset

Fahrenheit calculation formula: Compensated Target = -Slope\*(Current AT-32)+ Offset

## 2) Zone 2 target temperature setting interface


Click  to enter the target temperature in zone 2:



Number	Key name	Key function
①	Zone 2 Set Target WT	Click to set the zone 2 target outlet water temperature
②	Zone 2 Target RT	Click to set the zone 2 room target temperature, when Z01=4/5/6/7/8/9, it displays “/”
③	Zone 2 AT-WT Compensation	Click to enter the zone 2 weather compensation curve, When the zone 2 weather compensation is disable, it will display Not Used. Enable to display the compensated temperature. Enable condition:Z01=2/3/5/6/8/9 and Z17=1

# Operation and Use

## Zone 2 weather compensation curve



Number	Key name	Key function
①	Enable key	Enable weather compensation button.
②	Slope	Set the slope by sliding up and down or clicking on the value
③	Offset	Set the offset by sliding up and down or clicking on the value

### 3) Zone control function parameters

Click “[Parameter](#)” enter the password to enter the zone control function parameters□



# Operation and Use





A: Set Z01 to change the main zone control interface

When Z01=0, it means disable zone 1 and zone 2, display Not Used;


When Z01=2/5/8, it means disable Zone 1, Zone 1 will display Zone 1 Not Used;


When Z01=1/4/7, it means disable Zone 2, Zone 2 will display Zone 2 Not Used;

When Z01=3/6/9, it means enable Zone 1 and Zone 2.



## 1.3.2.2 Cooling Multi-Zone Control


When cooling or DHW+cooling mode, click “” to enter the multi-zone function interface:




1	Click to set the cooling target temperature
2	Click to set the zone 1 room target temperature
3	Click to set the zone 2 room target temperature

# Operation and Use


## 1.4 Unlock screen

After locking screen, click “” to pop up the following screen. Enter password to unlock.



## 2. Setting interface display and function

Swipe from right to left on the main interface to enter the function setting interface, and swipe from left to right on the function setting interface to return to the main interface. The function setting interface is shown in the figure below.



# Operation and Use


## Buttons description

Key number	Key name	Key function
①	Time setting	Click this key to set the time function.
②	Factory parameter	Click the key and enter the password to enter the factory parameter settings and status parameters interface.
③	Curve key	Click this key to view the temperature curve.
④	Smart grid	Click this key to Smart Grid
⑤	Adjust brightness	Click this key to adjust screen brightness
⑥	Fault	Click to view fault history
⑦	Electric Heater	Click to turn on/off the electric heater

### 2.1 Time setting



In the setup interface, tapping the button, then the interface display is shown as follows:




Key number	Key name	Key function
①	System Time	Click to set system time
②	Power Timer	Click to set timed switch on/off
③	Warm Water Cir. Control	Click to set warm water pump timed cycle, hide the icon when H40=0/2, show the icon when H40=1
④	Mute Timer	Click to set timed mute, hide the icon when H22=0, show the icon when H22=1

## 2.1.1 System time setting



In the time setting interface, click ① interface displays as follows:



When entering the page of system time setting, the system time will be initialized to the time at the moment when the system time setting button is pressed, and you can adjust the time by sliding up and down.


Note: When the temperature unit is °F, the time format is displayed as: month-day-year hour: minute: second.

# Operation and Use

## 2.1.2 Power Timer setting



In the time setting interface, click ② interface displays as follows:




NO.	Name	Button function
①	Timing switch function on	Clicking the button, when the font color is blue, the timing switch is on
②	Week setting	Set the day of the week to activate the timing switch
③	Time period setting	Set the time to turn on and the time to turn off
④	Turn page	A total of 6 timing switch time periods can be set, which can be selected by turning the page

# Operation and Use

## 2.1.3 Warm Water Cir. Control



In the time setting interface, click ③ interface displays as follows:




NO.	Name	Button function
①	Timing switch function on	Clicking the button, when the font color is blue, the timing switch is on
②	Week setting	Set the day of the week to activate the timing switch
③	Time period setting	Set the time to turn on and the time to turn off
④	Turn page	A total of 3 timing switch time periods can be set which can be selected by turning the page

# Operation and Use

## 2.1.4 Mute Timer setting



In the time setting interface, click ④ interface displays as follows:




NO.	Name	Key color	Button function
①	Whether enable the mute timer on function	Enable: Blue Disable: Gray	Click this key to enable or disable the mute timer on function
	Whether enable the mute timer off function	Enable: Blue Disable: Gray	Click this key to enable or disable the mute timer off function
②	The mute timer on setting point		select from 0:00-23:59
	The mute timer off setting point		select from 0:00-23:59
③	The status of mute timer on	Enable: Blue Disable: Gray	The status of mute timer on is shown
	The status of mute timer off	Enable: Blue Disable: Gray	The status of mute timer on is shown

# Operation and Use

## 2.2 Temperature Curve



In the setup interface, tapping the button, then the interface display is shown as follows:



Note:

- 1) This curve function records the water inlet temperature、 water outlet temperature、 tank water temperature and ambient temperature;
- 2) Temperature data is collected and saved every five minutes. Timekeeping is made from the latest data saving, if the power is disrupted when the time is less than five minutes, the data during such period will not be saved;
- 3) Only curve for power-on status is recorded, and that for power-off will not be saved;
- 4) The value of the abscissa indicates the time from the point on the curve to the current time point. The rightmost point on the first page is the latest temperature record;
- 5) Temperature curve record is provided with power-down memory function.



## 2.3 Smart Grid



In the setup interface, tapping the button, then the interface display is shown as follows:



Key number	Key name	Key function
①	SG Ready	Click to enter SG Ready
②	Mode&Temp.&Power Timer	Click to enter Mode&Temp.&Power Timer

### 2.3.1 SG Ready Function



#### 2.3.1.1 Disable SG Ready


When the Smart Grid Ready mode is not yet set, the interface will display:




# Operation and Use

## 2.3.1.2 Smart Grid Ready=1

When using one dry contact, the interface will display:



Click "Brief Description" to enter the function description screen:




# Operation and Use

Click "Parameter" and enter the password to enter the parameter setting screen:




## 2.3.1.2 Smart Grid Ready=2

When using two dry contacts, the interface will display:



# Operation and Use

Click "Brief Description" to enter the function description screen:



Click "Parameter" and enter the password to enter the parameter setting screen:




# Operation and Use

## 2.3.2 Mode&Temp.&Power Timer



Click “” to enter the Mode&Temp.&Power Timer screen:



NO.	Name	Button function
①	Enable key	Enable the timer,when the font color is blue, the timing switch is on
②	Function Description	Click to enter the function introduction
③	Time setting	Set timer time
④	Mode	Set target mode, If you don't need to control mode, please choose “/”
⑤	Target Temp.	Set target temperature
⑥	Max. Power	Set power limitation, Setting range 0.0~99.9KW. If you don't need to limite the power, please set “Max. Power” to 0.
⑦	Week setting	Set timer date
⑧	Turn page	A total of 6 timing switch time periods can be set, which can be selected by turning the page


# Operation and Use

---

## 2.4 Color Display Calibration



In the setup interface, tapping the button, then the interface display is shown as follows:



Note:


- 1) The middle display bar can be dragged or clicked to adjust the brightness of the screen, with power-down memory.
- 2) Press the back key to return to the previous level and save the brightness setting value.
- 3) The screen has the function of automatic on and off, if there is no operation for 30s, the screen will enter the half-time screen state.
- 4) If there is no operation for another 5 minutes, the screen will enter the screen state.

# Operation and Use

## 2.5.Fault interface display and function



In the setup interface, tapping the button, then the interface display is shown as follows:




①:Fault code ②:Fault name

③:Occurrence time of the fault: Day and month hour:minute:second

Note:If the current temperature is °F, occurrence time of the fault:  
Month and day hour: minute: second

④:Click this key to clear all fault records, enter the date of the day into the OK screen.




# Operation and Use

## 2.6 Electric Heater




In the setup interface, tapping the button, One-click to turn electric heater on or off. On is bright, off is grey.

Note: When electric heating is not enabled, the icon is hidden.



## 3. Status interface display

Swipe from left to right on the main screen to enter the main status screen. Swipe from right to left on the main status screen to return to the main screen interface. The main status screen displays the main status parameters.





## 4. Parameter list and breakdown table

### 4.1 Electronic control fault table

Can be judged according to the remote controller failure code and troubleshooting.

Protect/fault	Fault display	Reason	Elimination methods
Inlet Water Temp. Sensor Fault	P01	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Outlet Water Temp. Sensor Fault	P02	The temp. sensor is broken or short circuit	Check or change the temp. sensor
DHW Tank Sensor Fault	P03	The temp. sensor is broken or short circuit	Check or change the temp. sensor
AT Sensor Fault	P04	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Suction Temp. Sensor Fault	P17	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Heating Returning Water Temp. Sensor Fault	P013	The temp. sensor is broken or short circuit	Check or change the temp. sensor
DHW Returning Water Temp. Sensor Fault	P018	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Heating Leaving Water Temp. Sensor Fault	P023	The temp. sensor is broken or short circuit	Check or change the temp. sensor
DHW Leaving Water Temp. Sensor Fault	P028	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Room Temp. Sensor Fault	P42	The temp. sensor is broken or short circuit	Check or change the temp. sensor
EVI Inlet Sensor Fault	P101	The temp. sensor is broken or short circuit	Check or change the temp. sensor
EVI Outlet Sensor Fault	P102	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Distributor Tube Temp. Sensor Fault	P152	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Coil Temp. Sensor Fault	P153	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Exhaust Temp. Sensor Fault	P181	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Overhigh Exhaust Temp.	P182	The compressor is overload	Check whether the system of the compressor running normally
Anti-freezing Temp. Sensor Fault	P191	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Mix Tube Outlet Water Temp. Sensor Fault	P02a	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Buffer Tank Temp. Sensor Fault	P03a	The sensor is broken or short circuit	Check or change the temp. sensor
Pressure Sensor Fault	PP11	The pressure sensor is broken or short circuit	Check or change the pressure sensor or pressure
High Pressure Sensor Fault	PP12	The pressure sensor is broken or short circuit	Check or change the pressure sensor or pressure
Low AT Protection	TP	The ambient temp. is low	Check the ambient temp value
No Cooling at Low AT Protection	TC	The temp. sensor is incorrectly-detected or the temp.sensor is lower-than the set value A30	Check or change the temp. sensor
Electric Heater Overheat Fault	E04	The electric-heater protection switch is broken	Check whether the electric heater runs at the temperature above 150°C for a long time
Excess Temp. Diff. Between Inlet & outlet	E06	Water flow is not enough and low differential pressure	Check the pipe water flow and whether water system is jammed or not
Communication Fault	E08	Communication failure between wire controller and mainboard	Check the wire connection between remote wire controller and main board

# Operation and Use

Protect/fault	Fault display	Reason	Elimination methods
Primary Anti-freezing Fault	E19	The ambient temp. is low	Check the ambient temp value
Secondary Anti-freezing Fault	E29	The ambient temp. is low	Check the ambient temp value
Insufficient Defrosting Water Flow Alarm	E030	The unit flow rate is less than the minimum flow value of the unit.	Check or change waterway systems to provide unit flow
Flow Switch Fault	E032	No water/little water in water system	Check the pipe water flow and water pump
Overhigh Outlet Water Temp.	E065	No water/little water in water system	Check the pipe water flow and water pump
Low Outlet Water Temp. Temp. Fault	E071	No water/little water in water system	Check the pipe water flow and water pump
Fan Motor 1 and PCB Communication Fault	E081	Speed control module and main board communication fail	Check the communication connection
Fan Motor 2 and PCB Communication Fault	E082	Speed control module and main board communication fail	Check the communication connection
Display and PCB Communication Fault	E084	The wire controller software is not match the mainboard software	Check the wire control software number and the mainboard software number
Communication Fault with Hydraulic Module	E08c	Hydraulic Module and mainboard communication fail	Check the communication connection
HP Fault	E11	The high-pressure switch is broken	Check the pressure switch and cold circuit
LP Fault	E12	The low-pressure switch is broken	Check the pressure switch and cold circuit
Anti-freezing Fault	E171	Use side water system temp. is low	1. Check the water temp. or change the temp. sensor 2. Check the pipe water flow and whether water system is jammed or not
Fan Motor1 Fault	F031	1. Motor is in locked-rotor state 2. The wire connection between DC-fan motor module and fan motor is in bad contact	1. Change a new fan motor 2. Check the wire connection and make sure they are in good contact
Fan Motor2 Fault	F032	1. Motor is in locked-rotor state 2. The wire connection between DC-fan motor module and fan motor is in bad contact	1. Change a new fan motor 2. Check the wire connection and make sure they are in good contact
Zone 1 Room Temp. Sensor Fault	P105	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Zone 2 Room Temp. Sensor Fault	P106	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Zone 2 Mixing Temp. Sensor Fault	P107	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Abnormal Adjustment of Mixing Valve	E122	1. Mixing Valve is incorrectly connected; 2. Mixing Valve is damaged;	1. Plug and unplug terminals; 1. Replace the Mixing Valve;
Zone 1 Thermostat Communication Fault	E08g	1. Thermostat not connected 2. Thermostat failure 3. Wrong parameter setting	1. Check the wiring connection between the thermostat and the unit 2. Replace the thermostat 3. Check the parameters
Zone 2 Thermostat Communication Fault	E08h	1. Thermostat not connected 2. Thermostat failure 3. Wrong parameter setting	1. Check the wiring connection between the thermostat and the unit 2. Replace the thermostat 3. Check the parameters
Low Water Flow Protection	E035	Water flow is too low	Increased water flow

# Operation and Use

Frequency conversion board fault table:

Protect/fault	Fault display	Reason	Elimination methods
IPM Overcurrent Fault	F00	IPM Input current is large	Check and adjust the current measurement
Comp. Driver Fault	F01	Lack of phase, step or drive hardware damage	Check the measuring voltage check frequency conversion board hardware
Pre-Charge Failure	F03	The PFC circuit protection	Check the PFC switch tube short circuit or not
DC Power Bus Overvoltage Fault	F05	DC bus voltage>Dc bus Overload-voltage protection value	Check the input voltage measurement
DC Power Bus Undervoltage	F06	DC bus voltage<Dc bus Underload-voltage protection value	Check the input voltage measurement
AC Power Undervoltage Fault	F07	The input voltage is low, causing the input current is low	Check the input voltage measurement
AC Power Overcurrent Fault	F08	The input voltage is too high, more than outage protection current RMS	Check the input voltage measurement
Input Power Voltage Sampling Fault	F09	The input voltage sampling fault	Check and adjust the current measurement
DSP and PFC Communication Fault	F12	DSP and PFC connect fault	Check the communication connection
DSP and Comp. Driver Communication Fault	F11	DSP and Inverter board communication failure	Check the communication connection
Comp. Driver and PCB Communication Fault	F151	DSP and Mainboard communication failure	Check the communication connection
IPM Overheat Fault	F13	The IPM module is overheat	Check and adjust the current measurement
Comp. Overcurrent Fault	E051	The compressor is overload	Check whether the system of the compressor running normally
Input Power Lacking Phase Fault	F15	The input voltage lost phase	Check and measure the voltage adjustment
IPM Current Sampling Fault	F18	IPM sampling electricity is fault	Check and adjust the current measurement
Comp. Driver Temp. Sensor Fault	F17	The transducer is overheat	Check and adjust the current measurement
IGBT Power Device Overheat Alarm	F20	The IGBT is overheat	Check and adjust the current measurement
Comp. Weak Magnetic Alarm	F16	Compressor magnetic force is not enough	Check and adjust the current measurement
AC Input Current Frequency Decrease Alarm	F22	Input current is too large	Check and adjust the current measurement
EEPROM Alarm	F23	MCU error	Check whether the chip is damaged Replace the chip
Destroyed EEPROM & No Activated Fault	F24	MCU error	Check whether the chip is damaged Replace the chip
Input Power Current Sampling Fault	F25	The V15V is overload or undervoltage	Check the V15V input voltage in range 13.5V~16.5V or not
IGBT Overheat Fault	F26	The IGBT is overheat	Check and adjust the current measurement
Comp. Current Frequency Decrease Alarm	F33	The compressor current frequency reduction	Check and adjust the current measurement
AC Power Overvoltage Fault	F10	Input voltage>Input Overload-voltage protection value	Check whether the input voltage is higher than 265V
Compressor Lacking Phase Fault	F14	The compressor lost phase	Check whether compressor cables are connected properly and reliably
EEPROM Fault	F29	Failed to read the memory chip	Check the frequency conversion board
Overspeed Fault	F21	The compressor is running abnormally	Check whether the compressor cable is normal and whether the compressor is blocked

# Operation and Use


Protect/fault	Fault display	Reason	Elimination methods
Driver (Fan)Temp.Sensor Fault	F120	The temp. sensor is broken or short circuit	Check or change the temp. sensor
Driver (Fan)IPM Overheat Fault	F106	The fan IPM drive plate has poor heat dissipation	Check heat dissipation conditions
Driver (Fan) External Overcurrent Fault	F105	The fan IPM hardware running current is too large	Check whether the fan is blocked
Driver (Fan) Power Lacking Phase Fault	F101	The fan lost phase	Check whether fan cables are connected properly and reliably
Driver (Fan) Current Sampling Fault	F112	Fan sampling electricity is fault	Check whether the fan drive plate is abnormal
Driver (Fan) Start Fault	F102	The fan fails to start	Check whether the fan is blocked
Driver (Fan) Internal Overcurrent Fault	F113	The fan software running current is too large	Check whether the fan is blocked
Driver (Fan) overspeed Fault	F109	The fan speed is too high	Check whether the fan drive board is abnormal

## 4.2 Parameter list

Meaning	Default	Remarks
Cooling target temperature set point	12℃	Adjustable
Heating the target temperature set point	45℃	Adjustable
Hot water target temperature set point	55℃	Adjustable


## 5. Interface diagram

### 5.1 Wire control interface diagram and definition



Sign	Meaning
V	12V (power +)
A	485A
B	485B
G	GND(power-)

## 5.2 Controller interface diagram and definition



# Operation and Use

Main board of the input and output interface instructions below

Number	Sign	Meaning
01	AD1-1	Inlet Water Temp.
02	AD1-2	Outlet Water Temp.
03	AD1-3	Ambient Temp. (AT)
04	AD1-4	Coil Temp.
05	AD1-5	Suction Temp.
06	AD1-6	Antifreeze Temp.
07	AD1-7	Reserved
08	AD2-8	EVI Inlet Temp.
09	AD2-9	EVI Outlet Temp.
10	AD2-10	Room Temp. /Buffer Tank Temp
11	AD2-11	DHW Tank Temp.
12	AD2-12	Exhaust Temp.
13	AD3-13	Zone 1 room temp./Zone 1-P
14	AD3-14	Zone 2 room temp./Zone 2-P
15	AD3-15	Zone 2 Water Temp. after Mixing
16	AD3-16	Reserved
17	SW1-1	High Pressure Switch
18	SW1-2	Low Pressure Switch
19	SW1-3	Flow Switch
20	SW1-4	Electric Heater Overheat Fault
21	SW1-5	Remote Switch/SG-1
22	SW1-6	Heating / Cooling Mode Switch
23	SW1-7	Heating & Cooling Function Switch/SG-2
24	SW1-8	DHW Switch
25	SW1-9	Reserved
26	SW2-10	Reserved
27	SW2-11	Reserved
28	SW2-12	Reserved
29	CON1	220V input
30	JP1-1	Main Circulation Pump
31	JP1-2	Hot water 3-way valve
32	JP1-3	Electric Heater Stage 1
33	JP1-4	Electric Heater Stage 2
34	JP1-5	DHW Electric Heater
35	JP1-6	DHW circulating pump
36	JP2-7	Zone 1 pump
37	JP2-8	Zone 2 pump
38	JP2-9	Zone 2 Mixing valve Open
39	JP2-10	Zone 2 Mixing valve Closed
40	JP3-11	4-way valve
41	JP3-12	2-way valve
42	JP3-13	Crankcase Heater

# Operation and Use

---

43	JP3-14	Bottom Plate Heater
44	JP4-15	Cooling 3-Way Valve
45	JP4-16	Alarm
46	EEV1	EEV Steps
47	EEV2	EVI EEV Steps
48	EEV3	Reserved
49	EEV4	Reserved
50	PP1-1	Speed regulation of water pump
51	PP1-2	Reserved
52	PP2(0-10V_1+G)	Mixing valve output
53	CN203	Program port
54	JP800	12V output
55	SEN1-1	Low Pressure
56	SEN1-2	High Pressure
57	SEN1-3	Transformer Current 1
58	SEN1-4	Transformer Current 2
59	SEN2	Transformer Current 3
60	BUS1-3	DTU/Thermostat 1/Thermostat 2(Connected by user)
61	BUS1-2	Centralized control communication port
62	BUS1-1	Color display/DC fan speed regulationmodule/Frequency conversion board/Calibration tooling

**Note:**

PP1-1 represents VSP1, FG1, GND on the PP1 terminal;

PP1-2 represents VSP2, FG2, GND on the PP1 terminal;

SEN1-1 represents 5V1, IN1, GND on the SEN1 terminal;

SEN1-2 represents 5V2, IN2, GND on the SEN1 terminal;

SEN1-3 represents 5V3, IN3, GND on the SEN1 terminal;

SEN1-4 represents 5V4, IN4, GND on the SEN1 terminal;

BUS1-1 represents +12V, 485\_A1, 485\_B1, GND on the BUS1 terminal;

BUS1-2 represents +12V, 485\_A2, 485\_B2, GND on the BUS1 terminal;

BUS1-3 represents +12V, 485\_A3, 485\_B3, GND on the BUS1 terminal.

### Appendix 1 Caution & Warning

1. This machine can only be serviced by qualified installation center personnel or authorized dealers in the European market.
2. This appliance is not designed for use by individuals (including children) with reduced physical, sensory, or mental capabilities, or those with a lack of experience and knowledge, unless they have been supervised or instructed regarding the use of the appliance by individuals responsible for their safety in the European market .
3. Ensure that both the unit and the power connection are properly grounded to prevent the risk of electrical shock.
4. If the supply cord is damaged, it must be replaced by the manufacturer, an authorized service agent, or a similarly qualified individual to avoid potential hazards.
5. Directive 2002/96/EC (WEEE): The crossed-out waste bin symbol found underneath the appliance indicates that, at the end of its lifespan, this product must be disposed of separately from domestic waste. It should be taken to a recycling center for electrical and electronic devices or returned to the dealer when purchasing an equivalent appliance.
6. Directive 2002/95/EC (RoHS): This product complies with directive 2002/95/EC (RoHS), which restricts the use of certain hazardous substances in electrical and electronic devices.
7. The unit **MUST NOT** be installed near flammable gases to prevent the risk of fire in the event of a gas leak.
8. Ensure the unit is connected to a circuit breaker to prevent potential electrical shocks or fires.
9. The heat pump inside the unit is equipped with an overload protection system, which prevents the unit from restarting for at least 3 minutes after a previous shutdown.
10. For the North American market, this unit should only be serviced or repaired by qualified personnel from an installer center or an authorized dealer.
11. Installation in North America must be conducted according to NEC/CEC regulations, and only by authorized personnel.
12. Use supply wires suitable for a 75°C rating .
13. Caution: The unit contains a single-wall heat exchanger, which is not suitable for connection to potable water supplies.



# Appendix

## Appendix 2、Cable specification

### 1. Single phase unit

Nameplate maximum current	Phase line	Earth line	MCB	Creepage protector	Signal line
No more than 10A	$2 \times 1.5\text{mm}^2$	$1.5\text{mm}^2$	20A	30mA less than 0.1 sec	$n \times 0.5\text{mm}^2$
10~16A	$2 \times 2.5\text{mm}^2$	$2.5\text{mm}^2$	32A	30mA less than 0.1 sec	
16~25A	$2 \times 4\text{mm}^2$	$4\text{mm}^2$	40A	30mA less than 0.1 sec	
25~32A	$2 \times 6\text{mm}^2$	$6\text{mm}^2$	40A	30mA less than 0.1 sec	
32~40A	$2 \times 10\text{mm}^2$	$10\text{mm}^2$	63A	30mA less than 0.1 sec	
40~63A	$2 \times 16\text{mm}^2$	$16\text{mm}^2$	80A	30mA less than 0.1 sec	
63~75A	$2 \times 25\text{mm}^2$	$25\text{mm}^2$	100A	30mA less than 0.1 sec	
75~101A	$2 \times 25\text{mm}^2$	$25\text{mm}^2$	125A	30mA less than 0.1 sec	
101~123A	$2 \times 35\text{mm}^2$	$35\text{mm}^2$	160A	30mA less than 0.1 sec	
123~148A	$2 \times 50\text{mm}^2$	$50\text{mm}^2$	225A	30mA less than 0.1 sec	
148~186A	$2 \times 70\text{mm}^2$	$70\text{mm}^2$	250A	30mA less than 0.1 sec	
186~224A	$2 \times 95\text{mm}^2$	$95\text{mm}^2$	280A	30mA less than 0.1 sec	

### 2. Three phase unit

Nameplate maximum current	Phase line	Earth line	MCB	Creepage protector	Signal line
No more than 10A	$3 \times 1.5\text{mm}^2$	$1.5\text{mm}^2$	20A	30mA less than 0.1 sec	$n \times 0.5\text{mm}^2$
10~16A	$3 \times 2.5\text{mm}^2$	$2.5\text{mm}^2$	32A	30mA less than 0.1 sec	
16~25A	$3 \times 4\text{mm}^2$	$4\text{mm}^2$	40A	30mA less than 0.1 sec	
25~32A	$3 \times 6\text{mm}^2$	$6\text{mm}^2$	40A	30mA less than 0.1 sec	
32~40A	$3 \times 10\text{mm}^2$	$10\text{mm}^2$	63A	30mA less than 0.1 sec	
40~63A	$3 \times 16\text{mm}^2$	$16\text{mm}^2$	80A	30mA less than 0.1 sec	
63~75A	$3 \times 25\text{mm}^2$	$25\text{mm}^2$	100A	30mA less than 0.1 sec	
75~101A	$3 \times 25\text{mm}^2$	$25\text{mm}^2$	125A	30mA less than 0.1 sec	
101~123A	$3 \times 35\text{mm}^2$	$35\text{mm}^2$	160A	30mA less than 0.1 sec	
123~148A	$3 \times 50\text{mm}^2$	$50\text{mm}^2$	225A	30mA less than 0.1 sec	
148~186A	$3 \times 70\text{mm}^2$	$70\text{mm}^2$	250A	30mA less than 0.1 sec	
186~224A	$3 \times 95\text{mm}^2$	$95\text{mm}^2$	280A	30mA less than 0.1 sec	

When the unit will be installed at outdoor, please use the cable which can against UV.

# Appendix

## Appendix 3. Water quality requirements

### 1. Corrosion resistance of stainless steel and brazed materials in tap water at room temperature

Attention: + : Good corrosion resistance under normal conditions  
 0 : There may be corrosion problems  
 - : Not recommended

Moisture	Concentration	Time limit	Plate material			Brazing material		
			AISI 304	AISI 316	254 SMO	Cuprum	Nickel	SS
Alkalinity (HCO <sub>3</sub> )	<70	24h	+	+	+	0	+	+
	70-300		+	+	+	+	+	+
	>300		+	+	+	0/+	+	+
Sulfate (So <sub>4</sub> <sup>2-</sup> )	<70	unlimited	+	+	+	+	+	+
	70-300		+	+	+	0/-	+	+
	>300		+	+	+	-	+	+
HCO <sub>3</sub> <sup>-</sup> /SO <sub>4</sub> <sup>2-</sup>	>1.0	unlimited	+	+	+	+	+	+
	<1.0		+	+	+	0/-	+	+
Electrical conductivity	<10	unlimited	+	+	+	0	+	+
	10-500		+	+	+	+	+	+
	>500		+	+	+	0	+	+
pH	<6.0	24h	0	0	0	0	+	0
	6.0-7.5		+	+	+	0	+	+
	7.5-9		+	+	+	+	+	+
	>9		+	+	+	0	+	+
Ammonium (NH <sub>4</sub> <sup>+</sup> )	<2	24h	+	+	+	+	+	+
	2-20		+	+	+	0	+	+
	>20		+	+	+	-	+	+
Chloride (Cl <sup>-</sup> )	<10	unlimited	+	+	+	+	+	+
	100-200		0	+	+	+	+	+
	200-300		-	+	+	+	+	+
	>300		-	-	+	0/+	+	-

Note: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Note: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

