


- Fujitsu
- Mono-split
- Accessories
- Installation equipment



Accessories - Error report module type UTD-FSM216


Function

- Installation equipment

Applicable indoor units

- Type **AUYG LVLA/B**
- Type **AUYG LRLE/LRLA**
- Type **ARYG LMLE/LMLA**
- Type **ARYG LHTA**
- Type **ABYG LVTA/B**
- Type **ABYG LRTE/LRTA**
- Type **ASYG LFCA/C**

System Layout



Power Supply

Alarm notification