



## Accessories - Wireless remote controller type UTY-LNTY

### Brand

- Fujitsu - Airstage

### Product

- Single remote controller, wireless remote controller

### Application

- Controlling of one or group of indoor units.

### Applicable indoor units

- AUXG 07/09/12/14/18/22/24 KVLA

### Features

- Start/Stop operation and Start/Stop button
- Operation mode setting and Mode button
  - (AUTO,COOL,DRY,FAN,HEAT)
- Fan speed setting and Fan button
  - AUTO, HIGH, MED, LOW, QUIET
- Up and down airflow direction and swing button
- Reset button. Carries out a reset.
- Test run button. This button is used when the air conditioner is installed and cannot be used in normal conditions. Only allowed to be activated by authorized service personnel.
- Room temperature setting :
  - AUTO : 18 to 30°C
  - COOL/DRY : 18 to 30°C
  - HEAT : 16 to 30°C
- Built-in daily timer
  - PROGRAM timer : Operates the ON and OFF timer once within a 24 hour period.
  - SLEEP & NICE MORNING TIMER (Sleep button) :
    - SLEEP : This nocturnal disconnection program adjusts the microprocessor to the time of year to condition the room in an optimum manner before the user wakes up.
    - NICE MORNING TIMER (NMT) : This function calculates the time required for

the room to reach the desired temperature at the time set, and turns on the unit when required.

- ON timer: Switch ON the unit according to the time setting (From 1 to 24 hours - Daily)
- OFF timer: Switch OFF the unit according to the time setting (From 1 to 24 hours - Daily)
- Easy installation and operation
  - Code selector switch prevents indoor unit mix-up (Up to 4 code can be set)
  - Wide (120°) and precise transmitting range (max. 7m)
- Batteries and remote control unit holder included
  - Specifications : 1,5V (R03/LR03/AAA) x 2

**Dimensions**

- 145 x 90 x 30 (H x B x D) [mm]