

Fujitsu Unit 1

Fujitsu unit 2

Fujitsu Controle PCB

Fujitsu Controle PCB

EIB IN*

EIB IN*

1 2 3

1 2 3

6 7

12 13

USM 208

1 2

3 4 5

Power Supply

Alarm Noticication

